

Welcome. Lets get started.

Scan the code for a list of compatible motors and latest product information.



E-Door Connect



1 Plug it in.

Locate the E-Door connector port on the motor, align the pins correctly and gently push into the connector.

The status indicator will turn blue when it is ready to setup.



- Reset button
- Restart the device press once.
- Factory Reset press and hold until status LED flashes.



2 Setup the device.

Scan the code to download the Zimi app. Follow the instructions to add a new device and complete the setup.



Zimi App



3 Add Zimi Cloud Connect.

To control from anywhere or use a voice assistant, please install a Zimi Cloud Connect (sold separately).

Locate the device between your garage and Wi-Fi router.



Requires Wi-Fi with



4 Setup voice control.

Link your favourite voice assistant. Scan the code to visit Support and search for setup voice control.







support.zimi.life

We're here to help.

Please visit support.zimi.life for FAQs or send an e-mail to support@zimi.life Our friendly team are here to help you.



Status LED indicator

Blue

Ready to pair. 'Add new device' in Zimi to pair and complete setup. White

Setup complete. This device has been paired and setup completed. Pulsing

Identify device. This shows when the device settings are being changed.



ng in respect of any equip

Device issue A problem or update in progress. Please visit support for assistance.

E-Door Connect is for use with a compatible garage door motor, the list of compatible motors is available at https://zimi.life/product/e-door-conr Zimi requires a compatible (Android, IOS) mobile device, minimum OS requirements are available at the relevant download store. All feat functionally and other product specifications are subject to change without notice or obligation and certain features require a subscription.

Manufacturer's Warranty. This product has been manufactured to the highest quality standards. This product is warranted to the original purchaser and is not transferable. The product is guaranteed to be free from defects in workmanship and parts for a period of 2 Years from the date of purchase. Defects that occur within this warranty period, under normal use and care will be repaired, replaced or refunded. The benefits conferred by this warranty are in addition to all other rights and remedies of the consumer under a Commonwealth, State and Termtroly taws in rearning with the Purchaser. The warranty relates and Australian Consumer Law. Risk in regard to the product to be repaired shall at all times remain with the Purchaser. The warranty is given on the condition that the product to which it applies is used for the purpose and in the manner intended by its construction and for no other purposes whatsoever. Zimi Ltd shall not be responsible for damage of any kind, caused by accidents, power surges, electrical storm damage, incorrect power current, infestation (vermin or insect), incorrect installation, improper use of controls or failure to use unit in accordance with the operating instructions, general misuse or abuse or from normal wear and tear. Any attempt by an unauthorised person to repair or tamper with the equipment shall render the warranty null and void. Goods presented for repair under this warranty may be replaced by refurbished parts may be used to repair the goods. Zimi Ltds islability under this warranty is limited to the replacement and/or repair of the defective parts within the warranty period and does not extend to installation or removal of the product. Acceptance of liability by Zimi Ltd circulated herein is to the exclusion of any other remedy whatsoever and howsoever arising in respect of any interpret with the applies.

of of Purchase. Please keep your purchase docket or receipt as proof of purchase and as proof of the date on which the purchase w chase docket or receipt must be presented with the warranty when making a claim under this warranty. Failure to produce docume the date of original acquisition by the original Purchaser will result in a charge being levied for work done, labour and parts supplied. Likewise a charge will be made for any calls following warranty claim where no fault is found with the unit.

Service during the warranty period. The first point of contact for product issues is the place of purchase. The product must be returned original place of purchase for product repair, replacement or refund. Please ensure the product is properly packaged so as to ensure that no doccurs to the product during transit and make sure that you have included an explanation of the problem. In the event of goods requiring under manufacturer's warranty the owner is responsible for the cost of transportation. Should the goods be found to be in sound working on owner might be charged a fee.

Safety Warnings. Read all instructions and safety information. This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety. Young children should be supervised to ensure that they not play with the unit. Do not install the product in a location where water will splash onto it. Check and confirm that all connections are proper and secure to prevent causing property damages or injury. Do not install outdoor where it could be exposed to water or moisture (indoor use only)

th their operation (including time of opening and closing of the garage door wi Zimi app, provided by Zimi Ltd and any other electronic device (if any) which yc ow Zimi Ltd collects and handles data and your personal information, view the Privacy statement. The Products collect data associated with they operate). This data is collected and transmitted to the Zimioperate with the Products. For further information about how Z policy available at https://www.zimi.life/privacy-policy/ Trademarks. Zimi and their respective logos are registered trademarks of Zimi Ltd. The Bluetooth word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. Google and Google Play are trademarks of Google LLC. Amazon, Alexa and all relates logos are trademarks of Amazon.com, Inc. or its affiliates, Apple, the Apple logo, Apple Watch and IPP are are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries.